



**PlayCaller
Digital
Wireless
Communication
System**

SYSTEM SETUP FOR SYSTEMS INCLUDING ONE PRESSBOX RADIO


1

CHARGING:

Place batteries in the RAPID BATTERY CHARGER for 4 - 7 hours.

Red LED indicates charging.

Green LED indicates fully charged.



2

SET UP:

1) Begin with all radios off. Plug headsets into headset jack.

2) Identify the radio labeled PRESSBOX (#1).

3) Place Pressbox radio in the pressbox with all radios off.

4) Turn ON Pressbox radio. After 15 seconds, turn on Sideline radios one at a time.

* Pressbox radio antenna must have a clear line of sight to the field.

* All radios in the Pressbox should be a minimum of 3 feet apart.

* Clip Sideline radios to the right hip. Sideline radios can now move anywhere in the field/pressbox.

power



If signal is unclear, restart the Pressbox radio. It will automatically locate a free channel.

3

HEADSETS:

Porta Phone noise canceling microphones must be placed 1"-2" from the mouth for optimum voice translation.




4

SELECT CHANNEL & VOLUME:

channel selection

volume control





**PlayCaller
Digital
Wireless
Communication
System**

SYSTEM SETUP FOR SYSTEMS INCLUDING TWO PRESSBOX RADIOS


1

CHARGING:

Place batteries in the RAPID BATTERY CHARGER for 4 - 7 hours.

Red LED indicates charging.

Green LED indicates fully charged.



2

SET UP:

1) Begin with all radios off. Plug headsets into headset jack.

2) Identify the radios labeled PRESSBOX OFFENSE & PRESSBOX DEFENSE.

3) Place Pressbox radios in the pressbox with all radios off.

4) Turn ON Pressbox OFFENSE radio. After 15 seconds, turn on Sideline OFFENSE radios one at a time.

5) Turn ON Pressbox DEFENSE radio. After 15 seconds, turn on Sideline DEFENSE radios one at a time.

* Pressbox radio antennas must have a clear line of sight to the field.

* All radios in the Pressbox should be a minimum of 3 feet apart.

* Clip Sideline radios to the right hip. Sideline radios can now move anywhere in the field/pressbox.

power



If signal is unclear, restart the Pressbox radios. It will automatically locate a free channel.

3

HEADSETS:


Porta Phone noise canceling microphones must be placed 1"- 2" from the mouth for optimum voice translation.



4

SELECT CHANNEL & VOLUME:

channel selection



volume control